From:
Subject: FW: Ring Manual
Attachments: Ring Doorbell Manual.pdf

Jaime Smith

Detective - Property Crimes North Lakeland Police Department <u>City of Lakeland</u>

p. 863.834.8981 c. 863.608.1718



From: Smith, Jaime

Sent: Monday, December 17, 2018 9:44 AM

To: 'randall.w.smith14.civ@mail.mil' <randall.w.smith14.civ@mail.mil>

Subject: Ring Manual

Jaime Smith

Detective - Property Crimes North Lakeland Police Department City of Lakeland

p. 863.834.8981 c. 863.608.1718



From: Smith, Jaime

12/17/2018 09:44:23 AM Sent time: To: randall.w.smith14.civ@mail.mil

Subject: Ring Manual

Attachments: Ring Doorbell Manual.pdf

Jaime Smith

Detective - Property Crimes North Lakeland Police Department

City of Lakeland p. 863.834.8981 c. 863.608.1718



From: Smith, Jaime

12/17/2018 09:44:23 AM Sent time: To: randall.w.smith14.civ@mail.mil

Subject: Ring Manual

Attachments: Ring Doorbell Manual.pdf

Jaime Smith

Detective - Property Crimes North Lakeland Police Department

City of Lakeland p. 863.834.8981 c. 863.608.1718



Powering Your Ring



Charge your Ring Doorbell before installation using the supplied orange cable.

While charging, the circular light on the front of your Ring will let you know the percentage it's charged.

If you have an existing doorbell Ring can run off its existing power supply for a continuous charge (see step 6).

NOTE: Ring is not compatible with most intercom systems.

If you DON'T have an existing doorbell Ring can run off its built in battery and last 6-12 months between charges.

If you receive frequent motion events, you may need to charge your Ring more frequently.

Getting Ready for Setup Step 1


Say "Hello" to the back of your Ring

Setup Button – You'll be instructed to push the orange **setup button** during the in-app setup (see step 3).

While in setup mode, the light on the front of your Ring Doorbell will spin.

Charging Port – Plug the orange cable into the charging port to charge your Ring Doorbell.

Setup Button Charging Port



Download the Ring app



The Ring app will walk you through the entire installation process, but if you prefer to reference a hard copy, use this manual.

Visit: ring.com/app

Visit the online setup guide for extra help

We also have an online guide with videos and tutorials to help you set up and use your Ring Video Doorbell.

Visit: ring.com/setup

Step 2

Perform the in-app setup

The Ring app will walk you through this process.

Download the Ring app by visiting ring.com/app



Tap the plus sign in the Ring app to set up a new device, and select Video **Doorbell** when prompted.

Perform in-app setup near your router. **You'll need your** network name and Wi-Fi password.

Step 3

Push the front button to test video

While **inside near your router**, push the button on the front of your doorbell to see live video in the Ring app. Then, perform this same test while outside.



If video quality is not as good outdoors as it was indoors, you may need to move your router closer to your door or invest in a Wi-Fi extender.

Learn more at: ring.com/extender

Step 4

Remove your existing doorbell (optional)

If you're replacing a wired doorbell, first turn off the power at the breaker. Then, remove your doorbell from the wall, and disconnect the wires.



If your existing doorbell has a diode, you'll need to use the diode included with your Ring Doorbell for installation.



Step 5

Install the mounting bracket

Take everything that came in the box (along with a power drill if you're installing on **stucco**, **brick** or concrete), to the spot where you're installing your Ring Doorbell.




Snap the provided level onto the mounting bracket, and align the bracket accordingly.

Then, remove the orange tape, and use the mounting bracket as a template to mark four corner holes for your screws.

(continued)

Installing the mounting bracket

On **stucco**, **brick** or **concrete**, install the anchors using the provided drill bit and a power drill before installing the mounting bracket.



On **wood** or **siding**, you can skip this part and screw the bracket directly onto your wall.

If you have one, it may help to use a smaller drill bit to drill

pilot holes first.

Step 6

per state and local guidelines.

or directly into the wall until they're flush with the mounting bracket and the bracket is flat against the wall.



Connect the wires (optional)

your wall to the screws on the

Connect the wires coming out of

bracket. Note that it doesn't matter

which wire connects to which screw.

The wiring must be connected to a transformer with a voltage of 8VAC - 24VAC and an internal

doorbell or resistor. DC transformers and (therefore)

most intercoms are not supported.

How and when to use the diode

If your doorbell is digital (i.e. plays a melody), attach the included diode to the two screws on your bracket.

If it's mechanical (i.e. goes "dingdong"), DO NOT use the diode.




If you have a digital doorbell, connecting the diode the wrong way won't do any harm. If your doorbell doesn't ring, just reverse the diode.

Learn more at ring.com/diode

Attach Ring Doorbell to the bracket

Line up the holes in your Ring Doorbell with the slots on the bracket. Push firmly towards the wall and then down until you feel a click.



Step 8

Secure your Ring Doorbell Use the star-shaped end of your Ring

screwdriver to tighten the **security**

screws on the bottom of

your Ring Doorbell.

Then, restore

power at the

breaker.

The front light on your Ring Doorbell uses a number of patterns to communicate messages.

Here are some common ones:





Solid

Charge

Ring Speaker

Mode

Pushed

In Setup

Percentage

Flashing

You can toggle alerts for Rings or Motions on or off

in the Ring app

RING ALERTS

MOTION ALERTS

When someone is at your door, you

can perform the following actions:

Disable/enable your

Mute/unmute your speaker

Access the Ring Plus menu

Turning alerts on or off:

microphone

Zoom in/out

Need Help?

For additional help, visit: ring.com/help

For immediate assistance, we're available 7 days a week at: help@ring.com

US 1 800 656 1918

UK 01727 263045

AU 1 300 205 983

NZ +64 9 887 9871

Mexico (D.F) 52 55 8526 5445

For a list of all our customer support


Worldwide +1 310 929 7085

numbers, visit: ring.com/callus

Hereby, Bot Home Automation, declares that this consumer electronic is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The declaration of conformity may be consulted at www.ring.com/DoC.pdf. Protect the device from direct sunlight. Install the device at dry locations and protect it against rain and humidity. The device

NG, ALWAYS HOME, and CHIME are trademarks Bot Home Automation, Inc.





Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential

installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio However, there is no guarantee that interference will not occur

not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause

For best results, use type Li-Ion batteries. Install only new

batteries in the correct polarity, as indicated in the battery

compartment, may shorten the life of the batteries or cause

batteries to leak. Do not mix old and new batteries. Do not

mix Alkaline. Standard (Carbon-Zinc) or Rechargeable (Nickel

Cadmium) or (Nickel Metal Hydride) batteries. Do not dispose of batteries in fire. Batteries should be recycled or disposed of as

in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from

that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for

may not get contact to salt water or other conductive liquids. The device must be charged only within a building in a dry state.